

CMTD42M-F

Compact Module - Thermodynamic TrapFull Version (with 3 valves)

Description

The Forbes Marshall Compact Module Thermodynamic Trap, CMTD42M-F, is a compact thermodynamic trap module designed with an in built bypass valve, a trap vent valve and a trap test valve for steam applications upto 42 bar g. Replaceable trap internals and inbuilt strainer eases inline maintenance. The CMTD42M-F has an integral upstream and downstream piston valve, which isolates the upstream piping of the steam trap.

Sizes and Pipe Connections

DN 15, 20 Socket weldable end connection. (Available with # 150,300,600 weld on flanges on request)

Note: Available with IBR certificate on request

63 bar g at 100°C
425°C at 42 bar g
42 bar g
425°C at 42 bar g
0°C
80% of upstream
pressure
84 bar g



Limiting Conditions





Dimensions / Weight (approx.) in mm and kg (Valves in closed condition)

Size	Α	В	С	D	Е	F	G	н	Wt. (kg)
DN15	117	166	255	54	20	51	140	45	6.5
DN 20	117	166	255	54	20	51	140	45	6.5





Material

Sr. No	Part	Material
1	Body	ASTM A105
2	Bonnet	ASTM A105
3	DV1 Spacer	ASTM A276 Gr 410
4	DV1 Sealing Stack	SS 304 + graphite
5	Plain Washer	SS 304
6	Hex Lock Nut	SS 304
7	Hand Wheel	SG Iron 400/15A
8	Hex Nut LH	SS304
9	Stem Piston	ASTM A276 Gr 316
10	M8 Stud	ASTM A193 B7
11	Belleville Washer	Spring Steel
12	Hex Nut	ASTM 194 2H
13*	DV1 Plain Washer	SS 304
14	DV1 Stem Piston	ASTM A276 Gr 316
15	DV1 Lock Nut	ASTM A276 Gr 410
16	DV1 Bonnet	ASTM A276 Gr 410
17	DV1 Hex Knob	SG Iron 400/15A
18	DV2 Spacer	ASTM A276 Gr 410
19	DV2 Stem Piston	ASTM A276 Gr 316
20	DV2 Plain Washer	SS 304

Sr. No	Part	Material
21	DV2 Lock Nut	ASTM A276 Gr 410
22	DV2 Sealing Stack	SS 304 + Graphite
23	DV2 Bonnet	ASTM A276 Gr410
24	DV2 Hex Knob	SG Iron 400/15 A
25	Seat	Tool Steel AISI D2
26	Disc	Tool Steel AISI D2
27	Top Cover	ASTM A105
28	Screen	SS 304
29	Strainer Cap	ASTM 743 GR CA 40
30	Stud	ASTM A193 B7
31	Nut	ASTM 194 2H
32	Top Cover Gasket	SS304 + graphite
33	Inner Seat Gasket	SS304 + graphite
34	Outer Seat Gasket	SS304 + graphite
35	Nameplate	SS 304
36	DV1 Direction Plate	SS 304
37	DV2 Direction Plate	SS 304
38	DV3 Direction Plate	SS 304
39*	Rivet	SS 304
40	Ferrule	SS 304

*Item not shown



How to Order

Example: 1 No. DN 15 CMTD42M-F Compact Module -Thermodynamic Trap - Full Version (with 3 valves), socket weld able end connections, IBR

Installation

Ensure the following for the CMTD42M-F to operate correctly and remove condensate effectively.

- 1.The CMTD42M-F is installed with flow in the direction of the arrow. Flow to be horizontal.
- 2.Ensure that there is sufficient access to the hand-wheel to allow proper operation of both upstream and downstream isolation valves.
- 3.Ensure that there is sufficient access to the strainer to allow it to be cleaned periodically.
- 4.Allow sufficient access for the bypass valve, trap vent and trap test valve to operate.
- 5.Ensure all the valves are either full opened or tightly shut, and never kept partially open / crack open.

After 24 hours in service the cover nuts should be checked for tightness. Separate user manual which comes along with the product gives full details.

Bypass valve, trap vent valve and trap test valve Maintenance

Lubricate valve frequently with Molykote M30 oil or equivalent. Lubricate the stem piston and bonnet threading of drain valves DV1. Operate the valves after lubrication.

FORBES MARSHALL

Forbes Marshall Krohne Marshall Forbes Marshall Arca Codel International Forbes Solar Forbes Vyncke Forbes Marshall Steam Systems

Forbes Marshall USA (FM USA Inc.) 480 South California Avenue, Unit 102 Palo Alto, CA 94306 P: 650-327-4227 F: 650-327-4127

Email : fm.northamerica@forbesmarshall.com

Maintenance

To clean or replace strainer screen

Access to the strainer screen can be obtained by removing strainer cap. Remove strainer screen, fit new or cleaned strainer screen into recess of the cap. A new gasket should be fitted and the cap screwed into the body. The use of a thread lubricant is recommended.

To replace the cover studs

After removing old cover studs, fit new cover studs. The use of a thread lock (high temperature grade) is recommended.

Spares List

-		
	Description	Part No.
1	Spare Isolation Valve Internals Set (Sealing Stack, Spacer, Stem-Piston)	3,4,9
2	Spare for trap isolation valve/ trap bypass valve (DV1) Extractor Tool and Insertor Tool	Refer user manual
3	DV1 Spare Kit (Dome Nut, M6 Plain Washer, M6 Hex Nut, Sealing stack,Spacer,Stem- Piston)	3,4,5, 6,8,9
4	Spare Sealing Stack for isolation valve and trap bypass valve (Dv1)	4
5	CMTD42M-F Top Cover Stud and Nut Set	30, 31
6	15NB CMTD42M-F Seat, Disc	25, 26
7	20NB CMTD42M-F Seat, Disc	25, 26
8	CMTD42M-F Strainer Screen	28
9	CMTD42M-F Top Cover and Seat Gasket	32,33,34
10	Trap vent valve (DV2) and trap test valve	6,8,18,
	(DV3) Internals Set	19,20,22
11	Trap vent valve (DV2) and trap test valve	Refer
	(DV3) Extractor and Insertor Tool	manual

Recommended Tightening Torques

Description	Torque (Nm)
M8 Nuts (12)	10
M6 LH (8)	0.1
32 A/F (29)	142-158
M10x1.5 Studs (30)	20-25
17 A/F Nuts (19)	45-50

Forbes Marshall Canada Inc. 2425 Matheson Blvd East, 8th Floor Mississauga, ON L4W 5K4 P: 905-361-2880 F: 905-361-6401 Forbes Marshall Pvt. Ltd. B-85, Phase II, Chakan Indl. Area, Sawardari, Chakan, Tal. Khed. Dist. Pune - 410 501, India Tel. 91(0)2135-393400 www.forbesmarshall.com

All contents herein are the property of Forbes Marshall Private Limited ("FMPL") or Forbes Marshall Steam Systems Private Limited ("FMSSPL"), as the case may be, and having protection under the intellectual property rights. Any reproduction, distribution or disclosure without prior written permission is prohibited. Information in this document is subject to change without notice.



CMTD42M-S

Compact Module - Thermodynamic Trap Standard Version

Description

The Forbes Marshall Compact Module Thermodynamic Trap, CMTD42M-S, is a compact thermodynamic trap module designed with an in built upstream isolation piston valve and bypass valve for steam application up to 42 bar g. Replaceable trap internals and inbuilt strainer eases online maintenance. It comes with diffuser which gives smooth discharge and Isotub eliminates effects on performance irrespective of climatic conditions.

Sizes and Pipe Connections

DN 15, 20 Socket weldable,Screwed end connection. (Available with class 150, 300, 600 weld on flanges on request)

Note: Available with IBR certificate on request.

Limiting Conditions	
PMA Max. allowable pressure	63 bar g at 100°C
TMA Max. allowable temperature	425°C at 42 bar g
PMO Max. operating pressure	42 bar g
TMO Max. operating temperature	425°C at 42 bar g
Minimum operating temperature	0°C
Max. operating back pressure	80% of upstream pressure
Cold hydraulic test pressure	84 bar g (IBR Requirement)



Dimensions / Weight (approx.) in mm and kg (Valves in closed condition)									
Size	Α	В	С	D	Е	F	G	н	Weight
15NB	115	151	191	84	20	51	140	45	4.9 Kg
20NB	115	151	191	84	20	51	140	45	4.9 Kg



Forbes



Material

Sr. No	Part	Material
1	Body	ASTM A105
2	Bonnet	ASTM A105
3	DV1 Spacer	ASTM A276 Gr 410
4	DV1 Sealing Stack	SS 304 + graphite
5	Plain Washer	SS 304
6	Diffuser	SS 304
7	Hand Wheel	SG Iron 400/15A (ASTM A536)
8	Cleeve Lock Nut LH	SS304
9	Stem Piston	ASTM A276 Gr 316
10	M8 Stud	ASTM A193 B7
11	Belleville Washer	Spring Steel
12	Hex Nut	ASTM 194 2H
13	DV1 Plain Washer	SS 304
14	DV1 Stem Piston	ASTM A276 Gr 316
15	DV1 Lock Nut	ASTM A276 Gr 410
16	DV1 Bonnet	ASTM A276 Gr 410

Sr. No	Part	Material
17	DV1 Hex Knob	SG Iron 400/15 A (ASTM A 536)
18	Seat	Tool Steel AISI D2
19	Disc	Tool Steel AISI D2
20	Top Cover	ASTM A105
21	Screen	SS 304
22	Strainer Cap	BS 3146 PART2 ANC2
23	Stud	ASTM A193 B7
24	Nut	ASTM 194 2H
25	Top Cover Gasket	SS304 + graphite
26	Inner Seat Gasket	SS304 + graphite
27	Outer Seat Gasket	SS304 + graphite
28	Nameplate	SS 304
29	DV1 Direction Plate	SS 304
30	Rivet	SS 304
31	Ferrule	SS 304
32	ISOTUB	SS 304

Note: Material specification mentioned in bracket are for reference only.



How to Order

Example:DN15 CMTD42M-S Compact Module -Thermodynamic Trap - Standard Version socket weld able end connections,IBR

Installation

Ensure the following for the CMTD42M-S to operate correctly and remove condensate effectively.

1. The CMTD42M-S is installed with flow in the direction of the arrow. Flow to be horizontal.

2. Ensure that there is sufficient access to the hand-wheel to allow proper operation of upstream isolation valves.

3. Ensure that there is sufficient access to the strainer to allow strainer to be cleaned periodically.

4. Allow sufficient access for the bypass valve

5. Ensure all the valves are either full opened or tightly shut and never kept partially open/crack open.

After 24 hours in service the cover nuts should be checked for tightness. A separate user manual which comes along with the product gives full details.

Maintenance

To clean or replace strainer screen

Access to the strainer screen can be obtained by removing strainer cap. Remove strainer screen, fit new or cleaned strainer screen into recess of the cap. A new gasket should be fitted and the cap screwed into the body. The use of a thread lubricant is recommended.

To replace the cover studs

After removing old cover studs, fit new cover studs. The use of a thread lock (high temperature grade) is recommended.

Bypass valve maintenance

Lubricate valve frequently with Molykote M30 oil or equivalent. Lubricate the stem piston and bonnet threading.Operate the valves after lubrication.

Recommended Tightening Torques				
Item No.	Part	Torque(Nm)		
22	Strainer cap	142-158		
23	Cover studs	20-25		
24	Cover nuts	45-50		
12	M8 Nuts	10		
8	Cleeve lock nut	0.1		

Spares List

	Description	Part No.
1	Spare Isolation Valve Internals Set	3,4,9
2	Spare for trap isolation valve/ trap bypass valve (DV1) Extractor Tool and	Refer user manual
3	DV1 Spare Kit (Dome Nut, M6 Plain Washer, M6 Hex Nut, Sealing stack,Spacer,Stem-Piston)	3,4,5, 8,9
4	Spare Sealing Stack for isolation valve and trap bypass valve (DV1)	4
5	CMTD42M-S Top Cover Stud and Nut Set	23 , 24
6	15NB CMTD42M-S Seat, Disc	18 , 19
7	20NB CMTD42M-S Seat, Disc	18 , 19
8	CMTD42M-S Strainer Screen	21
9	CMTD42M-S Top Cover and Seat Gasket	25,26,27



Forbes Marshall Krohne Marshall Forbes Marshall Arca Codel International Forbes Solar Forbes Vyncke Forbes Marshall Steam Systems

Forbes Marshall USA (FM USA Inc.) 480 South California Avenue, Unit 102 Palo Alto, CA 94306 P: 650-327-4227 F: 650-327-4127

Email : fm.northamerica@forbesmarshall.com

Forbes Marshall Canada Inc. 2425 Matheson Blvd East, 8th Floor Mississauga, ON L4W 5K4 P: 905-361-2880 F: 905-361-6401 Forbes Marshall Pvt. Ltd. B-85, Phase II, Chakan Indl. Area, Sawardari, Chakan, Tal. Khed. Dist. Pune - 410 501, India Tel. 91(0)2135-393400 www.forbesmarshall.com

All contents herein are the property of Forbes Marshall Private Limited ("FMPL") or Forbes Marshall Steam Systems Private Limited ("FMSSPL"), as the case may be, and having protection under the intellectual property rights. Any reproduction, distribution or disclosure without prior written permission is prohibited. Information in this document is subject to change without notice.